

TOOLS NEEDED TO BUILD A PATIO COVER

With the installation of your aluminum lattice patio cover there are some Essential tools required and some that are optional no matter who the manufacturer is. There are also some *tools which you may or may not have access to but we'll include them because they will just make your job easier
These *Tools are easily rented.

- Razor knife
- Caulking gun
- *Cordless screwdriver
- Drill
- *Cordless Impact driver
- Levels - between 3' to *8'
- *Laser level
- Chop-saw with Carbide blade (we do not recommend a hack saw or sawzall)
- String
- Line Level
- Chalk-line
- Concrete nails
- Stakes
- Speed-square
- Pencil or china marker (No sharpie)
- Numbers #8, #10, #12, #14 Hex Head adapters
- Hex Head extension bit 2-4"
- Saw horses or table length of the longest member
- Hammer
- Roto Hammer drill
- 3/8" concrete drill bit
- 3/16" concrete drill bit
- Step bit up to 5/8"
- Spade bit 5/8"
- "Blue tape"
- Gloves
- Safety Glasses
- Ladders 6'-10' or *scaffolding or both

